



SP90

ART.NO. 112439

**EN**

## INSTALLATION INSTRUCTIONS

CS2500 - Expansion module/IO-module

*Our products are subject to continuous development and we therefore reserve the right to make changes. We also disclaim liability for any printing errors that may occur.*

## Contents

|        |   |    |
|--------|---|----|
| 1.     | Product description .....                                     | 6  |
| 2.     | Commission Modbus modules.....                                | 6  |
| 3.     | Installation .....  | 7  |
| 3.1.   | Login.....  | 7  |
| 4.     | Connections .....   | 7  |
| 5.     | Configuration .....   | 8  |
| 6.     | Additional cooling .....                                      | 8  |
| 7.     | Additional heating.....                                       | 10 |
| 7.1.   | For water heating .....                                       | 10 |
| 7.1.1. | For configuration of water heating.....                       | 10 |
| 7.1.2. | For configuration of circulation pump for water heating ..... | 10 |
| 7.1.3. | For parameter setting of the water heating .....              | 11 |
| 7.2.   | For electric heating.....                                     | 11 |
| 7.2.1. | For configuration of electric heating .....                   | 12 |
| 7.2.2. | For parameter setting of the additional heating.....          | 12 |
| 8.     | Fire fan.....   | 14 |
| 9.     | External setpoint .....                                       | 15 |
| 9.1.   | For configuration of external setpoint.....                   | 15 |
| 9.2.   | For parameter setting of external setpoint.....               | 15 |
| 10.    | Mixing damper .....   | 16 |
| 10.1.  | For configuration of the heating sequence .....               | 17 |
| 10.2.  | For parameter setting .....                                   | 17 |
| 11.    | Technical data.....   | 18 |
| 12.    | Dimensions .....  | 20 |
| 13.    | Recycling.....  | 21 |

## Symbols



**DANGER!** When a text box is this colour, it means that a life-threatening or serious personal injury may be the consequence of not following the instructions.



**NOTICE!** When a text box is this colour, it means that a poor utilisation ratio or product operating issues may be the consequence of not following the instructions.



**CAUTION!** When a text box is this colour, it means that material damage may be the consequence of not following the instructions.



**INFO!** When a text box is this colour, it means that it contains important information.



## SAFETY INSTRUCTION



- To avoid the risk of fire, electric shock or injury, read all the safety instructions and warning texts before using the unit.
- All electrical connections must be carried out by qualified electricians.
- If the power lead is damaged, it must be replaced by the manufacturer, the manufacturer's service agent or a similarly qualified person.
- The unit must not be used to extract combustible or flammable gases.
- It is the installer's responsibility to carry out a full safety and function assessment of the appliance.
- All electrical power to the unit must be shut off before carrying out service or maintenance, including cleaning:
  1. Switch off the unit in the following menu on the handheld terminal: 'Start page > SERVICE SWITCH > OFF'.
  2. Wait until the unit has stopped.
  3. Switch off the all-pole switch.



- This unit is only designed for ventilation air in homes and commercial buildings.
- To maintain a good indoor climate, comply with regulations and avoid condensation damage, the unit must never be stopped apart from during service/ maintenance or in connection with an accident.
- The unit must not be operated without the filters being in place.
- All plumbing work must be carried out by an authorised plumber.
- The location of the water battery must be approved by a plumber owing to the risk of water leaks.
- Check whether the unit's operating voltage is 400V or 230V.
- The electric battery must be configured in accordance with the operating voltage.

## 1. Product description

SP90 is an extension module that can be connected to a CS2500 controller.

The extension module offers the following features:

- Power supply AC 24 V or DC 24 V via the controller
- 8 universal I/Os (configurable inputs / outputs, for analog or digital signals)
- 4 relay outputs (NO contacts)
- 2 analog outputs (DC 0...10 V)



**DANGER!** All electrical connections must be carried out by qualified electricians.

## 2. Commission Modbus modules

CS2500 controller and the expansion module SP90 are involved in this action:



fig. 1




fig. 2





fig. 3




### 3. Installation

Complete following tasks to install the expansion module:

| Step | Action  |
|------|---|
| 1    | Disconnect the power for CS2500-Controller  |
| 2    | Connect the expansion module to the unit with the enclosed contact. Connect the two units to each other with the contact. (See fig. 1)  |
| 3    | Connect the units that are required for the desired functionality. Use the enclosed contacts. (See fig. 2)<br><b>OBS! The external components are not included in this accessory, they have to be ordered separately.</b> |
| 4    | Adjust dip-switch according to fig. 3.  |
| 5    | Connect the CS2500 controller to power.   |
| 6    | Installation is done, but you have to configure it to get the correct function.   |

#### 3.1. Login

 Two keys means that you need to be logged in at level 3 to be able to make changes. The password for this level is "2000".


See the main manual for the regulator for more information about logging in and different levels.

### 4. Connections

| Step | DO | Function  |
|------|----|---|
| Q13  | DO | Fire fan  |
| Q14  | DO | Fire fan  |
| Q23  | DO | Free  |
| Q24  | DO | Free  |
| Q33  | DO | Additional cooling, pump                          |
| Q34  | DO | Additional cooling, pump                          |
| Q43  | DO | Additional water/electric heating                 |
| Q44  | DO | Additional water/electric heating                 |
| Y1   | AO | Mixing damper (0-10V)                             |
| M    | -  | G0  |
| Y2   | AO | Additional cooling (0-10V)                        |
| X1   | AI | External temperature setpoints (0-10V)            |
| M    | -  | G0  |
| X2   | AI | Temperature, exhaust                              |
| X3   | AI | Temperature frost guard, additional heating       |
| M    | -  | G0  |
| X4   | AI | Temperature, supply air, with additional sequence |
| X5   | AO | Additional heating (0-10V)                        |
| M    | -  | G0  |
| X6   | DI | Alarm, additional electric heating                |
| X7   | -  | Free  |
| M    | -  | G0  |
| X8   | -  | Free  |

## 5. Configuration

Proceed as follows to configure the expansion module:

|  | Step | Action  |
|--|------|---|
|  | 2    | Choose Main index > Configuration > Configuration 1 > Expansionsmodules               |
|  | 3    | Choose "One".   |
|  | 4    | Choose "Restart" and then "execute"   |
|  | 5    | Main configuration is now done, and the system will restart.                          |
|  | 6    | If the configuration is performed correctly both BSP and BUS will have a green light. |

### Activate functions:

You have to activate the functions that you are going to use. Choose the sections that match the different functions.

## 6. Additional cooling

The default function of the main regulator is to control two heating and three cooling steps. The SP90 module can control additional steps, either in sequence or as a standalone temperature zone.

An additional cooling coil can be connected to the system. It can be included in the temperature regulation loop in two different ways, either as a separate temperature zone (standalone) or as part of the ordinary sequence.

To activate the function:



**Start page > Main menu > Configuration > Configuration 1 > Additional cooling**

| Parameter | Function   |
|-----------|--|
| Water     | Analogue output for liquid cooling                         |
| DX 1step  | One digital output for DX cooling                          |
| DX 2steps | Two digital outputs for DX cooling, regulate in sequence.  |
| DX 3steps | Two digital outputs for DX cooling, regulate binary.       |
| ModBus    | ModBus controlled valve in combination with liquid cooling |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



**RESTART**


To configure the function:



**Start page > Main menu > Configuration > Configuration 2 > Cooling 2 control**

| Parameter  | Function   |
|------------|--|
| Sequence   | Additional cooling is included in the cooling sequence after the ordinary cooling steps DX1-DX3  |
| Standalone | Additional cooling is regulated separately independently of the ordinary temperature regulation.<br><b>NB!</b> This function requires installation of an additional supply air sensor. |





If 'Standalone' is selected, the setpoint for Additional cooling is adjusted via:



**Start page > Quick menu > Settings > Setpoints/Settings**

| Parameter                | Function   |
|--------------------------|--|
| Setpoint additional seq. | Indicates the supply air temperature for Additional cooling in 'Standalone' mode |

For other cooling settings, see chap. 6 Cooling in the main manual.

| Block no. | Function                              |
|-----------|---------------------------------------|
| Q33       | Q33 Additional cooling/DX1            |
| Q34       | Q34 Additional cooling/DX1            |
| Q43       | Q43 Additional cooling/DX2            |
| Q44       | Q44 Additional cooling/DX2            |
| X4        | Supply air sensor, Additional cooling |
| M         | Supply air sensor, Additional cooling |
| Y2        | Additional cooling 0-10V              |
| M         | Additional cooling GO                 |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



**RESTART**

After the restart, outputs for the DX steps must be selected.



**Start page > Main menu > Configuration > Config. In/Outputs> Temp. control outputs>**

Ex. DX cooling output1 = 1Q3  
Ex. DX cooling output2 = 1Q4

## 7. Additional heating

An additional heating coil can be connected to the system. It can be included in the temperature regulation in two different ways, either as a separate temperature zone (standalone) or as an additional coil as part of the ordinary sequence.

### 7.1. For water heating

To activate the function:



**Start page > Main menu > Configuration > Configuration 1 > Additional Water heating**

| Parameter                       | Function   |
|---------------------------------|--|
| Yes                             | Additional liquid heating activated  |
| Yes+Preh.Outdoor temp.          | Additional liquid heating activated as pre-heating and controlled by the outdoor temperature     |
| Yes+Preh.Frost protection temp. | Additional liquid heating activated as preheating and controlled by the frost temperature sensor |
| ModBus                          | ModBus controlled valve in combination with liquid heating                                       |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



RESTART

#### 7.1.1. For configuration of water heating



**Start page > Main menu > Configuration > Configuration 2 > Frost protection, additional Water heating**


| Parameter   | Function   |
|-------------|--|
| No          | No frost protection                                  |
| Sensor      | Frost protection via sensor                          |
| Sensor+2 sp | Frost protection via sensor and two set-points       |
| Guard       | Frost protection via guard                           |
| Sens+Guard  | Frost protection via sensor and guard                |
| 2sp+Guard   | Frost protection via sensor, two setpoints and guard |

#### 7.1.2. For configuration of circulation pump for water heating



**Start page > Main menu > Configuration > Configuration 2 > Pump, additional Water heating.**

| Parameter  | Function                                       |
|------------|--|
| No         | No circulation pump activated                  |
| Yes        | Circulation pump without maintenance operation |
| Yes+Motion | Circulation pump with maintenance operation    |



| Block no. | Function                              |
|-----------|---------------------------------------|
| X3        | Return water sensor                   |
| M         | Return water sensor                   |
| X4        | Supply air sensor, additional heating |
| M         | Supply air sensor, additional heating |
| X6        | Frost guard (digital input)           |
| M         | Frost guard (digital input)           |
| Q43       | Pump output, additional heating       |
| Q44       | Pump output, additional heating       |
| X5        | Additional heating 0-10V              |
| M         | Additional heating GO                 |



**Start page > Main menu > Configuration > Configuration 2 > Additional water heating regulation**

| Parameter                        | Function   |
|----------------------------------|--|
| Standalone                       | Additional heating is regulated separately independently of the ordinary temperature regulation<br><b>NB!</b> This function requires installation of an additional supply air sensor |
| Seq.: Heating-Additional heating | Additional heating is included in the heating sequence AFTER the ordinary heating step   |
| Seq.: Additional heating-Heating | Additional heating is included in the heating sequence BEFORE the ordinary heating step  |

After making a change in a configuration menu, a restart is required.

**Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**

**RESTART**

### 7.1.3. For parameter setting of the water heating

**Start page > Main menu > Unit > Temperature regulation > Additional water heating**

| Parameter                | Function  |
|--------------------------|---|
| Regulator                | Current heating regulator value                                   |
| Output signal            | Current value at analogue output                                  |
| Setpoint additional seq. | Setpoint for additional sequence when Standalone mode is selected |
| Frost protection         | Current frost regulator value                                     |
| Pump                     | Current pump status   |
| Preheating               | Current preheating mode   |
| Frost guard              | Current position of frost guard                                   |

If 'Standalone' is selected, the setpoint for Additional water heating is adjusted via:

**Start page > Quick menu > Settings > Setpoints/Settings**

| Parameter                | Function   |
|--------------------------|--|
| Setpoint additional seq. | Indicates the supply air temperature for Additional water heating in 'Standalone' mode |

## 7.2. For electric heating

To activate the function:



**Start page > Main menu > Configuration > Configuration 1 > Additional electric heating**

| Parameter | Function  |
|-----------|---|
| No        | No additional electric heating coil activated             |
| Analogue  | Additional heating coil with analogue control activated   |
| 1Step     | Additional one-step electric heating register activated   |
| 2Step     | Additional two-step electric heating register activated   |
| 3stepBin  | Additional three-step electric heating register activated |

After the restart, outputs for the electric steps must be selected.



**Start page > Main menu > Configuration > Config. In/Outputs > Temp. control outputs >**

Additional electric heating output1 = 1Q3  
Additional electric heating output2 = 1Q4

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**


**RESTART**

### 7.2.1. For configuration of electric heating



**Start page > Main menu > Configuration  
> Configuration 2 > Alarm, additional  
electric heating**

| Parameter | Function                 |
|-----------|--------------------------|
| No        | No alarm input activated |
| Yes       | Alarm input activated    |



| Block no. | Function                               |
|-----------|--|
| X5        | Analogue output electric heating 0–10V |
| M         | Analogue output electric heating G0    |
| X6        | Fire thermostat DI                     |
| M         | Fire thermostat DI                     |
| Q23       | Electric heating output 1 DO           |
| Q24       | Electric heating output 1 DO           |
| Q43       | Electric heating output 2 DO           |
| Q44       | Electric heating output 2 DO           |



**Start page > Main menu > Configuration  
> Configuration 2 > Additional electric  
heating regulator**

| Parameter                        | Function   |
|----------------------------------|--|
| Standalone                       | Additional heating is regulated separately independently of the ordinary temperature regulation<br><b>NB!</b> This function requires installation of an additional supply air sensor |
| Seq.: Heating-Additional heating | Additional heating is included in the heating sequence AFTER the ordinary heating step   |
| Seq.: Additional heating-Heating | Additional heating is included in the heating sequence BEFORE the ordinary heating step  |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration >  
Configuration 2 > Restart > Execute**



**RESTART**

### 7.2.2. For parameter setting of the additional heating



**Start page > Main menu > Unit >  
Temperature regulation > Additional  
electric heating**

| Parameter                | Function   |
|--------------------------|--|
| Regulator                | Current heating regulator value  |
| Output signal            | Current value at analogue output                                       |
| Operation                | Current position of electric heating register                          |
| Setpoint additional seq. | Setpoint for additional sequence when Standalone mode is selected      |
| Alarm                    | Alarm mode for additional heating                                      |
| Start step 1             | Heating regulator value in % for start of first step                   |
| Start step 2             | Heating regulator value in % for start of second step                  |
| Start step 3             | Heating regulator value in % for start of third step                   |
| Hysteresis, power down   | Power down hysteresis in % of steps                                    |
| Max.signal fan st.       | Limits the maximum heating requirement in % at the different fan steps |

> Example of start step and power down hysteresis and limitation of heating requirement at different fan steps

|   |                    |
|---|--------------------|
| Start step 1 = 20%  | Start step 2 = 40% |
| Fan step 1 = 30%  | Fan step 2 = 60%   |
| Power down hysteresis = 10%   |                    |
| Heating step 1 switches in at 20% heating requirement and remains at max. 30% force while the fan is on step 1. Switches off when the heating requirement has fallen to 10%.                                |                    |
| Heating step 2 switches in at 40% heating requirement and remains at max. 60% force while the fan is on step 2. Switches off when the heating requirement has fallen to 30% or the fan goes down to step 1. |                    |



**Start page > Quick menu > Settings > Setpoints/Settings**

If "Standalone" is selected, the setpoint for Additional electrical heating is adjusted via:

| Parameter                 | Function  |
|---------------------------|---|
| Setpoint addi-tional seq. | Indicates the supply air temperature for Additional electric heating in 'Standalone' mode |

## 8. Fire fan

The unit has a potential-free output to control an external fire fan. This function is activated via the fire/smoke input. This assumes that the fire alarm function is activated in the automatic control system (see main manual).

Configure as follows::



**Main menu > Configuration > Configuration 1 > Fire fan**

| Parameter | Function             |
|-----------|----------------------|
| Yes       | Function activated   |
| No        | Function deactivated |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



**RESTART**

After the restart, the unit starts with an alarm: 'No config. IO' This means that an output must be defined for the fire fan function.

This is done via:



**Main menu > Configuration > Config. Inputs/Outputs > Outputs, Fans > Fire fan Select**


| Parameter | Function  |
|-----------|---|
| Q11       | Selected unless the operating mode indication function is activated |
| Q12       | Selected unless the DX step 2/3 function is activated               |

To switch contact function for the output:



**Main menu > Unit > Outputs > Fire fan > Contact function**

| Parameter | Function               |
|-----------|------------------------|
| NO        | Output normally open   |
| NC        | Output normally closed |



| Valg | Block no. | Function        |
|------|-----------|-----------------|
| Q11  | Q13       | Fire fan output |
|      | Q14       | Fire fan output |
| Q12  | Q23       | Fire fan output |
|      | Q24       | Fire fan output |


## 9. External setpoint

The temperature setpoint can be controlled externally. It is possible to specify whether the external setpoint is to be used as setpoint compensation or an absolute value. The value corresponds to the comfort setpoint.



**Start page > Main menu > Configuration > Configuration 1 > External setpoint**

| Parameter | Function   |
|-----------|--|
| No        | External setpoint deactivated                            |
| Volt      | External setpoint activated and regulated via 0-10 V     |
| Ohm       | External setpoint activated and regulated via 0-2.5 kOhm |
| QAA27     | Not used   |
| BSG21     | Not used   |



| Block no. | Function                       |
|-----------|--------------------------------|
| X1        | External setpoint signal 0-10V |
| M         | External setpoint G0           |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



### 9.1. For configuration of external setpoint



**Start page > Main menu > Configuration > Configuration 2 > Ext. setp. function**

| Parameter | Function              |
|-----------|-----------------------|
| Comp.     | Setpoint compensation |
| Main      | Main setpoint         |

#### > Example of setpoint compensation

The comfort setpoint is set to +20 degrees

Ext. setpoint curve Y1 = -5

Ext. setpoint curve Y2 = +5

0 V at the input produces a setpoint of +15 degrees

10 V at the input produces a setpoint of +25 degrees

#### > Example of main setpoint

Ext. setpoint curve Y1 = +10

Ext. setpoint curve Y2 = +30

0 V at the input produces a setpoint of +10 degrees

10 V at the input produces a setpoint of +30 degrees

The comfort setpoint in the regulator has no function

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**



### 9.2. For parameter setting of external setpoint




**Start page > Quick menu > Settings > Setpoints/Settings > All settings > External setpoint**

| Parameter              | Function                                |
|------------------------|---|
| Ext. setpoint curve Y1 | Indicates the lowest external setpoint  |
| Ext. setpoint curve Y2 | Indicates the highest external setpoint |

## 10. Mixing damper

A mixing damper can be installed to recycle the extract air back into the supply air duct. This can be done with up to 80% recycled air and 20% outdoor air. The following is a simplified summary of the components involved.

All dampers must have a 0–10V control system for stepless regulation between open and closed position.




P3997Z07

To activate the function:




**Start page > Main menu > Configuration > Configuration 1 > Mixing damper**

| Parameter             | Function  |
|-----------------------|---|
| Active                | Mixing damper activated, output signal 100% for full circulation.       |
| Invert                | Mixing damper activated, output signal 0% for full circulation.         |
| MB Extract air        | Not used  |
| MB Supply air         | Not used  |
| MB Mixing             | Not used  |
| Limit extract air fan | The extract air fan is controlled by the position of the mixing damper. |



| Block no. | Function                       |
|-----------|--------------------------------|
| Y1        | Damper output 0-10V Mix damper |
| x         | Damper output G0 Mix damper    |
| P12-32    | +24V power supply Mix damper   |



After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



**RESTART**



## 10.1. For configuration of the heating sequence



**Start page > Main menu > Configuration > Configuration 2 > Mixing damper sequence**

| Parameter      | Function  |
|----------------|---|
| Damper-Heating | Mixing damper primary, heating register (recovery system+heating) secondary |
| Heating-Damper | Heating register (recovery system+heating) primary, mixing damper secondary |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**



### > Example of mixing damper

At the start, the mixing damper is entirely open during the period for Start time if outdoor air temperature < Start temp. The regulator determines the current position after this period.

If heating is required at the start, the heating register is activated in parallel and after start has been completed the mixed air regulator for heat recovery is set to max. (100% - Min. outdoor air).

## 10.2. For parameter setting



**Start page > Main menu > Unit > Temperature regulation > Mixing damper**


| Parameter        | Function  |
|------------------|---|
| Regulator        | Current regulator value for mixed air   |
| Output signal    | Current value for damper actuator   |
| Recovery         | Shows current heat recovery. For Mixing damper = Normal, this value is always the same as the output signal. For Mixing damper = Inverted, this value is always the inverted output signal. |
| Min. outdoor air | Minimum outdoor air/minimum position of damper. Here the minimum airflow can be set as a percentage. This ensures that a certain volume of outdoor air is always blown into the room.       |
| Start time       | Time for the regulator's start process (100% recirculation).  |
| Start temp.      | Temperature limit for start process   |

## 11. Technical data

| Technical data            |  |  |
|---------------------------|--|--|
| Power supply              | Operating voltage<br>Frequency<br>Power consumption<br>Connection  | AC 24 V $\pm 20\%$ ; DC 24 V $\pm 10\%$<br>45...65 Hz<br>(AC) 600 mA, (DC) 340 mA<br>Peripheral bus  |
| Relay outputs Q1...Q4     | Relay: Type, contact<br>Contact rating<br>Switching voltage<br>Nominal current (res. / ind.)<br>Switching current at AC 19 V                 | Monostable, NO contact<br><br>AC 24 V...230 V (-20%, +10%)<br>Max. AC 4 A / 3 A ( $\cos\phi$ 0.6)<br>Min. AC 30 mA   |
| Universal I/Os<br>X1...X8 | Configurable<br>Reference potential<br>Contact voltage<br>Over voltage protection Up to 40 V   | Via software<br>Terminals<br>Max. DC 24 V (SELV)<br>Up to 40 V   |
|                           | Analog inputs (X1...X8)<br>Ni1000<br>Sensor current<br>Resolution<br>Accuracy within the range -50...150 °C                                  | <br><br>1.4 mA<br>0.1 K<br>0.5 K   |
|                           | Pt1000<br>Sensor current<br>Resolution<br>Accuracy within the range -40...120 °C   | <br><br>1.8 mA<br>0.1 K<br>0.5 K   |
|                           | NTC 10k (B25/85 = 3977K)<br>Sensor current<br>Temperature range<br>-50...-26 °C<br>-25...74 °C<br>75...99 °C<br>100...124 °C<br>125...150 °C | 140 $\mu$ A<br>Accuracy<br>Resolution<br>1 K 0.2 K<br>0.5 K 0.1 K<br>1 K 0.3 K<br>3 K 1.0 K<br>6 K 2.5 K   |
|                           | NTC 100k (B25/85 = 3977K)<br>Sensor current<br>Temperature range<br>-25...-11 °C<br>-10...9 °C<br>10...99 °C<br>100...150 °C                 | 140 $\mu$ A<br>Accuracy<br>Resolution<br>3 K 0.2 K<br>1 K 0.1 K<br>0.5 K 0.1 K<br>1 K 0.2 K  |
|                           | 0...2,500 $\Omega$<br>Sensor current<br>Resolution<br>Accuracy   | 1.8 mA<br>1 $\Omega$<br>4 $\Omega$   |
| Peripheral bus            | Power supply   | U <sub>eff</sub> = AC 24 V $\pm 20\%$ , f <sub>main</sub> = 45...65 Hz or<br>U = DC 24 V $\pm 10\%$ , no internal fuse   |
|                           | Bus termination selectable<br>Solid wire<br>Stranded wire (twisted and with ferrule)<br>Cable lengths<br>Addressing<br>Termination           | (680 $\Omega$ / 120 $\Omega$ +1 nF / 680 $\Omega$ )<br>0.2...1.0 mm <sup>2</sup><br>0.2...1.0 mm <sup>2</sup><br>Max. 30 m<br>DIP switches 1...5<br>DIP switch 6 |

| Technical data           |  |  |
|--------------------------|--|--|
| Environmental conditions | Operation<br>Temperature<br>Humidity<br>Atmospheric pressure   | IEC 721-3-3 class 3K5<br>-40...70 °C<br><90% r.h. (non-condensing) Min. 700 hPa,<br>corresponding t max. 3,000 m above sea level   |
|                          | Transport<br>Temperature<br>Humidity<br>Atmospheric pressure   | IEC 721-3-2 class 2K3/2K4<br>-40...70 °C<br><95% r.h. (non-condensing) Min. 260 hPa,<br>corresponding to max. 10,000 m above sea level   |
| Protection               | Degree of protection<br>Safety class   | IP20 (EN 60529)<br>Suitable for use in plants with safety class II   |
| Standards                | Product safety<br>Automatic electrical controls  | EN 60730-1   |
|                          | Electromagnetic compatibility<br>Immunity in the industrial sector Emissions in the domestic sector  | EN 61000-6-2<br>EN 61000-6-3   |
|                          | CE conformity<br>EMC directive<br>Low-voltage directive  | 2004/108/EC<br>2006/95/EC  |
|                          | Listings   | UL916, UL873<br>CSA C22.2M205  |
|                          | RoHS directive   | 2002/95/EC (Europe<br>ACPEIP (China)   |
| General data             | Dimensions of controller<br>Weight excl. packaging<br>Base<br>Housing  | 108 x 110 x 75 mm<br>183.5 g<br>Plastic, pigeon-blue RAL 5014<br>Plastic, light-grey RAL 7035  |
| Status of LEDs           | The status of the BSP LED is defined as follows:<br><br>Status<br>Red blinking at 2 Hz<br>Green on<br><br>The status of the BUS LED is defined as follows:<br><br>Status<br>Red on<br>Green on<br>Green on and red on (yellow) | Meaning<br>BSP error or slave address error<br>BSP running<br><br><br><br>Meaning<br>Communication error<br>Communication running<br>Communication running but parameter not successfully configured |

## 12. Dimensions



### 13. Recycling

The module contains electrical and electronic components and must not be disposed of together with household waste.

Local and existing legislation must be observed!







Flexit AS, Televeien 15, N-1870 Ørje  
[www.flexit.no](http://www.flexit.no)