

# STOPPBRYTER

N

## Monteringsveiledning

Bryter for næringsbyggaggregater og boligaggregater med vannvarme.

### Flexit S20/S30

Koble inn på utlagte rekkeklemmer **X:3** og **G0**.  
Når det blir kontakt mellom X:3 og G0 vil aggregatet stanse.  
Aggregater med elvarme stanser etter ca 3min (ettergangstid).

### Flexit L20/L30/L50

Koble inn på utlagte rekkeklemmer **X:7** og **G0**.  
Når det blir kontakt mellom X:7 og G0 vil aggregatet stanse.  
Aggregater med elvarme stanser etter ca 3min (ettergangstid).

### Flexit L12/L18/S9/S12

Koble direkte på styrekortet på **S:35** og **G0**.  
Når det blir kontakt mellom S:35 og G0 vil aggregatet stanse.  
Aggregater med elvarme stanser etter ca 3min (ettergangstid).

**VIKTIG: Denne bryteren skal ikke alene bli brukt som servicebryter, da skal det i tillegg brukes en bryter med allpolig brudd på tilførselspenning til aggregatet.**

# STOP SWITCH

E

## Installation Guide

Switch for business building units and home units with water batteries.

### Flexit S20/S30

Connect to the connected terminal blocks **X:3** and **G0**.  
When connection is made between X:3 and G0 the unit will stop.  
Air handling units with electrical batteries stop after approx. 3 minutes (fan afterblow).

### Flexit L20/L30/L50

Connect to the connected terminal blocks **X:7** and **G0**.  
When connection is made between X:7 and G0 the unit will stop.  
Air handling units with electrical batteries stop after approx. 3 minutes (fan afterblow).

### Flexit L12/L18

Connect directly to the control board at **S:35** and **G0**.  
When connection is made between S:35 and G0 the unit will stop.  
Air handling units with electrical batteries stop after approx. 3 minutes (fan afterblow).

**IMPORTANT: This switch must not be used as the only service switch. In addition an electrical circuit breaker (all-pole disconnections) must be installed on the units electrical supply cable.**